

EDGE INTELLIGENCE

LAB - 5

25MML0038


SUBHASHINI M

EDGE IMPLUSE


STEPS:

1. Create an account on **Edge Impulse**.
2. Login to the Edge Impulse platform.
3. Create a **new project**.
4. Click **Data Acquisition**.
5. Select **Connect to device**.
6. Choose **Use mobile phone** and scan the QR code.
7. Connect the mobile phone as a camera.
8. Capture sample images.
9. Collect images for **training** and **testing**.
10. Rename images with meaningful names.
11. Label all images correctly.

Training -8




Testing-6




Steps to Create an Image Classification Model in Edge Impulse


1. Open **Impulse Design** and click **Create Impulse**.
2. Add a **Processing Block** as **Image**.
3. Add a **Learning Block** as **Image Classification**.
4. Click **Save Impulse**.
5. In **Impulse Design**, click on **Image**.
6. Click **Generate Features** to extract image features.
7. After feature generation is complete, go to **Image Classification** (Classifier).
8. Click **Start Training**.
9. Once training is finished, the **model accuracy** will be displayed for the images you uploaded.




CREATE IMPLUSE



IMAGE




CLASSIFIER



Error Fix and Image Classification Training in Edge Impulse

1. An error occurred because **Bounding box labeling** was used with an **Image Classification** model.
2. To fix this, go to **Dashboard** and change the labeling method to **One label per data item**.
3. Properly relabel all images using **single class labels** (no bounding boxes).
4. In **Impulse Design**, add **Image** as the processing block and **Image Classification** as the learning block.
5. Generate features, train the model, and the classifier achieved **100% accuracy**.

DASHBOARD



CLASSIFIER

The screenshot displays the Edge Impulse web interface, specifically the 'Classifier' configuration page. The interface is divided into several sections:

- Neural Network settings:**
 - Training settings:** Number of training cycles (80), Use learned optimizer (checked), Learning rate (0.0005), Training processor (CPU).
 - Advanced training settings:** Validation set size (20%), Split train/validation set on metadata key (empty), Batch size (32), Auto-weight classes (checked), Profile int8 model (checked).
 - Neural network architecture:** Input layer (27,648 features), 2D conv / pool layer (16 filters, 3 kernel size, 1 layer), 2D conv / pool layer (32 filters, 3 kernel size, 1 layer), Flatten layer, Dropout (rate 0.25), Add an extra layer, Output layer (2 classes).
- Training output:** Shows the progress of training, including creating embeddings, calculating performance metrics, and extracting TensorBoard logs. The status is 'Job completed (success)'.
- Model:** Model version: Quantized (int8).
- Last training performance (validation set):** ACCURACY 100.0%, LOSS 0.04.
- Confusion matrix (validation set):**

	FAN	MOUSE
FAN	100%	0%
MOUSE	-	-
F1 SCORE	1.00	-
- Metrics (validation set):**

Metric	Value
Weighted average Precision	1.00
Weighted average Recall	1.00
Weighted average F1 score	1.00
- Data explorer (full training set):** A scatter plot showing data points for FAN - correct (green) and MOUSE - correct (yellow).
- On-device performance:** INFERRING TIME 339 ms, PEAK RAM USAGE 182.8K, FLASH USAGE 70.4%.

The interface also includes a sidebar with navigation options like Dashboard, Devices, Data acquisition, Experiments, EON Tuner, Impulse design, and Upgrade Plan. The bottom of the screen shows a Windows taskbar with various application icons and the system clock.